



TX-928-H

Operating Manual



CONTENTS

Product Introduction	2
Product Features	2
Technical Datas	3
LCD Display and Functions	4
Dimensions	5
General Setting	6-7
Advanced Setting	8-9
Wiring Diagrams	10
Installation Diagrams	10
Trouble Shooting	11

Product Introduction

TX-928-H series are available for boiler, manifold and underfloor heating system with 7-day, 6-period time program control. Models are with NTC sensor to detect ambient and floor temperature and do the control by compared with the setting one. Manual, time program and temporary mode can be switched any time by pressing the relevant keys. De-frost protection function will be active when ambient temperature below 5°C , prevent water pipe from freezing and burning.



Product Features

- 1、7-day, 6-period time program
- 2、Touch screen LCD with blue backlight
- 3、De-frost protection $\leq 5^{\circ}\text{C}$
- 4、Key-lock function
- 5、Memory function (can not memorized on/ off condition)
- 6、Advanced setting
- 7、Double sensors to control and limit the temp.
- 8、Ingress Protection:IP20
- 9、Flame retardant PC

Technical Datas

Consumption: <2W

Power supply: 85~240VAC 50/60Hz

Output switch: Active contact (NO) and passive contact (NO)

Max. Current 20 Amp Max

On/ Off differential temp.: 1~5°C

Transport and storage temp.: -20~60°C

Relative humidity: 10%~90% (No condensation)

Setting temp.: 5~35°C/0.5°C per step

Accuracy: 1°C

Temp. limitation: 30~60°C(external sensor)

Wiring port: 2.5 mm² at least

Working temp.: 0~50°C

LCD display and Functions

1. Manual control mode


LCD displays “☀”, the controller is under manual setting. In the “ON” state, press “☒” to switch the manual control mode or time program control mode.

2. Time control mode

LCD displays “☺”, adjust temperature of periods automatically against time program setting. In the “ON” state, press “☒” to switch the time program control mode or manual control mode.


3. Temporary control mode

LCD displays “☁” and “☺”, current period is manual control mode, but next period resume to the time program control mode. In the time program control mode, press “☒” or “☑” to enter into temporary control mode.




LCD display


Dimensions



①



③



②






















① Front View

② Back View









③ Left View








Unit:mm

General Setting


1. Power on / off: Press “” to turn on or turn off the controller. When power is off, it displays “OFF” and current time alternatly; when power is on, it displays setting temp. and current time alternatly.
2. Adjust setting temp.: Press “” or “”to adjust temp. during manul control and temporary control mode.
3. Key-lock function: In the “ON” state, keep pressing “” for 3s until the coin “LOC” displays, to lock or unlock the controller.
4. Time and week setting: In the “ON” state, press “”, then press “” or “” to amend the minute; press “” to amend the hour; press “” to set the day of week, press “” to save and exit the setting.
5. Time program: In the “ON” state, keep pressing “” to start setting, press “” or “” to adjust the current time(15mins/step). Press “” again to check related temp., press “” or “”to adjust setting temp.. Press “” to adjust next period. Press “” to save and exit the setting.
6. Control mode: Press “” to switch manual or time program control mode. In time control mode, keep pressing “” or “”to enter into temporary control mode.


General Setting


Periods	Coins	Default Time	Default Temperature
Weekdays	1 	06: 00	22°C
	2 	08: 00	
	3 	11: 30	
	4 	12: 30	
	5 	17: 00	
	6 	22: 00	
Holiday	1 	08: 00	
	2 	23: 00	

-  Wake up, Period 1
-  Leave(am), Period 2
-  Return(am), Period 3
-  Leave(pm), Period 4
-  Return(pm), Period 5
-  Sleep, Period 6
-  Key-LOC

Advanced Setting


Normally set by technicians during the first installation. Press “

Tips: (Amend the datas via advanced setting, press “

01. Adj Temperature compensation, press “

Main output from “OFF” to “ON”: Action temp.=setting temp.-differential temp.

Main output from “ON”to“OFF”: Action temp.=setting temp.+differential temp.

05. Prg 5+2/6+1/7 or off, press “

Tips: workdays divided into 6 periods, and holidays divided into 2 periods only .

Advanced Setting

06. Rle Setting of passive linkage and main output, press “ Δ ” or “ ∇ ” to change the condition of linkage; “00” means correspond with main loop output, “01” means opposite. Press “ Enter ” to enter into next setting.

07. Dly Dry contact function output delay: Press “ Δ ” or “ ∇ ” to amend from 0-5minutes, press “ Enter ” to enter into next setting.

When the output from “ON” to “OFF”, dry contact will be “OFF” at the same time.


08. Hit Press “ Δ ” or “ ∇ ” to adjust the max.temp. from 35~60°C. Press “ Enter ” to enter into next setting.

09. Fac Recover factory setting, press “ Δ ”, then the coin “-” appears on the screen, hold on until it changes to “- -”, finishes recover factory setting. Press “ Enter ” to enter into next setting; or press “ Enter ” to save and exit of setting.

Setting	01	02	03	04	05	06	07	08
Default	0	1N	35	1	5	00	00	35


Wiring Diagrams

The highest elevation for the controller working under full load situation is 2500m; or if higher than 2500m, the rated power of external loads should be $\leq 80\%$ rated power of the thermostat.




Wiring diagrams


Installation Diagrams




1. Insert the screwdriver into the gap to detach the back cover and iron plate of the thermostat



2. Fix the iron plate with screw and install it on the junction box in the wall



3.To correctly connect the wires as the wiring diagram



4.Insert the thermostat and fix it on the iron plate

Trouble Shooting

Fault phenomenon	Reasons	Methods
No display	Power line input errors or without Input	Check the power line connection and the power supply
Display Er1	Internal sensor errors	Check the pin of internal sensor if there is a short circuit
Display Er2	External sensor errors	Check the pin of external sensor if there is a short circuit. Choose internal sensor via advanced setting